

## CT440 Container Door Lock Fitting Instructions

A minimum clearance of 6mm is required between container door and rear of door bar.



## **Fitting**

- 1. Slide hooks behind door bars whilst slotting both parts together.
- 2. Insert lock into nearest available hole.

## To Operate Lock.

Insert key, rotate ¼ turn and insert lock into receiver. Turn key ¼ turn clockwise and remove key.

We have taken every care in the design and manufacture of this security device and we believe that it is an effective deterrent.

However we cannot guarantee that it will resist the efforts of the most determined thief, and as such we do not accept any liability for loss or damage caused by theft, vandalism or other illegal activity against property to which this device is fitted.

## **Bulldog Security Products**

Units 1 - 4 Stretton Road, Much Wenlock, Shropshire, TF13 6DH.

Tel: 01952 728171 Fax: 01952 728117

Email sales@bulldogsecure.com www.bulldogsecure.com cT05

Lock Lubrication.

IMPORTANT - To ensure free movement of the lock, spray lock mechanism with WD40 (or equivalent) minimum every four months.