DOOR ACCESSORIES

The **ERA Concealed Door Chain** gives extra security for external doors and is fitted concealed in the door frame. Push button operation facilitates quick and easy locking and is especially suitable for the elderly. When in the locked position, conversation can take place through the door whilst being secured. The Concealed Door Chain can only be unlocked when the door is closed.

Concealed Door Chain



